

VACUUM BRAKE FITTINGS FOR DRIVING TROLLEYS

For compatability with G.M.E.S. passenger stock vacuum brakes it is recommended that the drivers brake valve be attached permanently to the driving trolley.

